



For your safety, please read the following before using.

- Check the regulator and flow adjustment valve before introducing the fluid. If the pressure or flow rate exceeded the specified range, the sensing element may be damaged.
- The sensing element cannot measure properly if foreign matter adheres to it.
- On the inlet side, be sure to install an air filter below the filtration level of 10um.
- Recommended Equipments and Installation




NOTE: Please install a throttle valve on the outlet side of the sensor to prevent errors caused by unstable flow.


- Use straight piping 8cm or longer to connect the Piping Port (inlet side). If straight piping is not installed, the accuracy may vary by ±2% F.S.. Avoid sudden changes in the piping size on the inlet side of the product. Do not release the outlet side piping port of the product directly to the atmosphere without the piping connected. (※ Straight Piping: The pipe is without bending and the cross sectional areas of the pipe keeps the same.)
- When piping, please apply I.D. 9 mm or more air tube.
- Please use a wrench on the metallic area and torque property. When piping with metallic area, please refer to the applicable torque below. Over torquing may be damaged the product. When insufficient torque, the connection may loosen to cause air leakage. After installation completed, please make gas and power on and operate properly and test leakage to verify the installation correct.



A. PANEL DESCRIPTION




B. ORDERING INFORMATION



C. OPERATION INSTRUCTIONS






1 Function Selection Mode

At Measurement Mode, press [F-01] button for more than 3 sec. to display [F-01]. Press [▲] or [▼] button to select other setting functions. Press [F-01] for 3 sec. at Function Setting Mode to return to Measurement Mode.

















2 [F-01] OUT1 Setting Selection














1. Flow sensor setting




2. Pressure sensor setting



5 [F-08] Analog Output Selection



11 Key Lock / Unlock Mode



E. FUNCTION INSTRUCTION

Function Code	Item	Explanation
[F-01]	[out1] OUT1 setting	Select Output 1 corresponding to flow sensor or pressure sensor. Set the flow rate or pressure value to switch ON/OFF.
[F-02]	[out2] OUT2 setting	Select Output 2 corresponding to flow sensor or pressure sensor. Set the flow rate or pressure value to switch ON/OFF.
[F-03]	[Lor] LCD Display color selection	Select back light color and display mode.
[F-04]	[rESP] Response time selection	Select the response time for analog output. Pressure sensor: 2.5ms ~ 1500ms. Flow sensor: 50ms ~ 1500ms.
[F-05]	[UPdR] Display refresh time selection	Display refresh cycle can be set in 200ms, 500ms or 1000ms.
[F-06]	[Unit] Unit selection	Select the UNIT of pressure / flow sensor.
[F-07]	[rEFE] Flow reference standard selection	Select the flow value is shown under standard (ANR) or normal condition (NOR).
[F-08]	[RnG] Analog output selection	Select the analog corresponding to pressure or flow sensor.
[F-09]	[EEP] Accumulated value hold selection	To save the last accumulated flow value every 2 or 5 minutes.
[F-10]	[d15] Flow sensor display mode selection	Select to display Instantaneous Flow or Accumulated Flow Mode.
[F-80]	[55n] Sync the value of flow analog output and display	Turn ON to synchronize the value of flow analog output and display. (※) (Default setting : OFF)
[F-91]	[ECo] Power-Save mode selection	Select if turn on power-save mode to reduce power consumption
[F-92]	[inP] External input selection	Select for Accumulated flow rate zero clear, Auto-Shift or Auto-Shift zero.
[F-94]	[rEnE] Fine adjustment setting	The displayed value can be adjusted slightly.
[F-95]	[FoUt] Forced output function	To force output ON/OFF to test the switch function.
[F-99]	[rESt] Reset to the default setting	Return to the factory default setting.


※ Note : This function is available for output of flow rate only.

F. ERROR CODE INSTRUCTION


Error Type	Error Code	Error Condition	Troubleshooting		
OUT1 Excess Load Current Error	Er1	Output 1 load current is more than 125 mA.	Turn power off and check the cause of overload current or lower the current load under 125 mA, then restart.		
	Er2				
OUT2 Excess Load Current Error	Er3	Output 2 load current is more than 125 mA.	Perform the zero clear function again under no flow conditions.		
	Er4				
Zero Adjustment Error	Er5	The instant flow is within ±5% F.S. of the zero point.	Perform the zero clear function again under no pressure conditions.		
	Er6				
System Error	Er7	The pressure value is over ±3% F.S. of the zero point.	Perform the zero clear function again under no pressure conditions.		
	Er8				
System Error	Er9	Memory error	Turn power off, and then restart. If error condition remains, please return to factory for inspection.		
	Er10				
	Er11				
Applied Flow/Pressure Error	Err	The instant flow has exceeded the upper limit of the flow display range.	Reduce the flow to the display range.		
	Err			The pressure has exceeded the upper limit of the pressure display range.	Reduce the pressure to the display range.
	Err				
Applied Flow/Pressure Error	Err	The instant flow has exceeded the lower limit of the flow display range.	Ensure the flow is in the correct direction.		
	Err			The pressure has exceeded the lower limit of the pressure display range.	Increase the pressure to the display range.

For your safety, please read the following before using.

- Check the regulator and flow adjustment valve before introducing the fluid. If the pressure or flow rate exceeded the specified range, the sensing element may be damaged.
- The sensing element cannot measure properly if foreign matter adheres to it.
- On the inlet side, be sure to install an air filter below the filtration level of 10um.
- Recommended Equipments and Installation Example




※ NOTE : When measuring the pressure of the inlet side, install a throttle valve or solenoid valve on the outlet side.



※ NOTE : When measuring the pressure of the outlet side, install a throttle valve or solenoid valve on the inlet side.

A. PANEL DESCRIPTION



B. ORDERING INFORMATION

P R 0 3 0 1 0 3 P 1

Flow Rate Range

- 01 : 100 L/min
- 02 : 200 L/min

Port Size

- 03 : Rc1/4", with internal threads

Output Specifications

- P1 : 2 PNP output + Analog output 1~5V
- P2 : 2 PNP output + Analog output 4~20mA


Optional Parts

- PR03B01 : Mounting bracket

C. OPERATION INSTRUCTIONS





1 Function Selection Mode

At Measurement Mode, press **[F-0]** button for more than 3 sec. to display **[F-0]**. Press **[Δ]** or **[▽]** button to select other setting functions. Press **[F-0]** for 3 sec. at Function Setting Mode to return to Measurement Mode.






2 [F-0] OUT1 Setting Selection


1. Flow sensor setting




2. Pressure sensor setting




Normal Open Mode



Window Comparator Mode




Accumulated Pulse Output Mode




※ NOTE :
 1. In case hysteresis is set at less than or equal to 2 digits, switch output may chatter if input pressure fluctuates near the set point.
 2. When using window comparator mode, the difference between two set points must be greater than the fixed hysteresis, otherwise will cause the switch output to malfunction.

3 [F-02] OUT2 Setting Selection




4 [F-07] Flow Reference Standard Selection




※ NOTE :
 1. Standard condition (ANR): the display value is calculated under 20°C, 1atm.
 2. Normal condition (NOR): the display value is calculated under 0°C, 1atm.
 3. Flow rate in the specification is the value at standard condition (ANR).


5 [F-08] Analog Output Selection




6 [F-10] Flow Sensor Display Mode Selection




7 [F-80] Sync the value of flow analog output and display




8 Pressure Zero Adjustment Function




9 Instantaneous Flow Zero Adjustment Function



10 Reset Accumulated Flow Function



11 Key Lock / Unlock Mode



D. FUNCTION INSTRUCTION

Function Code	Item	Explanation
[F-01]	[oUt1] OUT 1 setting	Select Output 1 corresponding to flow sensor or pressure sensor. Set the flow rate or pressure value to switch ON/OFF.
[F-02]	[oUt2] OUT 2 setting	Select Output 2 corresponding to flow sensor or pressure sensor. Set the flow rate or pressure value to switch ON/OFF.
[F-03]	[CLoR] LCD Display color selection	Select back light color and display mode.
[F-04]	[rESP] Response time selection	Select the response time for analog output. Pressure sensor: 2.5ms ~ 1500ms. Flow sensor: 50ms ~ 1500ms.
[F-05]	[uPDR] Display refresh time selection	Display refresh cycle can be set in 200ms, 500ms or 1000ms.
[F-06]	[Un t] Unit selection	Select the UNIT of pressure / flow sensor.
[F-07]	[rEFE] Flow reference standard selection	Select the flow reference is shown under standard (ANR) or normal condition (NOR).
[F-08]	[RnG] Analog output selection	Select the analog corresponding to pressure or flow sensor.
[F-09]	[EEP] Accumulated value hold selection	To save the last accumulated flow value every 2 or 5 minutes.
[F-10]	[d15] Flow sensor display mode selection	Select to display Instantaneous Flow or Accumulated Flow Mode.
[F-80]	[54n] Sync the value of flow analog output and display	Turn ON to synchronize the value of flow analog output and display. (※) (Default setting : OFF)
[F-91]	[ECo] Power-Save mode selection	Select if turn on power-save mode to reduce power consumption
[F-92]	[rnP] External input selection	Select for Accumulated flow rate zero clear, Auto-Shift or Auto-Shift zero.
[F-94]	[r nE] Fine adjustment setting	The displayed value can be adjusted slightly.
[F-95]	[FoUt] Forced output function	To force output ON/OFF to test the switch function.
[F-99]	[rESE] Reset to the default setting	Return to the factory default setting.

※ Note : This function is available for output of flow rate only.

E. ERROR CODE INSTRUCTION

Error Type	Error Code	Error Condition	Troubleshooting
OUT1 Excess Load Current Error	8001 Er1	Output 1 load current is more than 125 mA.	Turn power off and check the cause of overload current or lower the current load under 125 mA, then restart.
OUT2 Excess Load Current Error	8002 Er2	Output 2 load current is more than 125 mA.	Turn power off and check the cause of overload current or lower the current load under 125 mA, then restart.
Zero Adjustment Error	8003 Er3	The instant flow is within ±5% F.S. of the zero point.	Perform the zero clear function again under no flow conditions.
	Er3 200	The pressure value is over ±3% F.S. of the zero point.	Perform the zero clear function again under no pressure conditions.
System Error	Er4 Er4	Memory error	
	Er5 Er5	Internal data error	Turn power off, and then restart. If error condition remains, please return to factory for inspection.
	Er6 Er6	Internal data error	
Applied Flow/Pressure Error	Er7 Er7	System parameter error	
	8004 XXX	The instant flow has exceeded the upper limit of the flow display range.	Reduce the flow to the display range.
	XXX 200	The pressure has exceeded the upper limit of the pressure display range.	Reduce the pressure to the display range.
	8005 LLL	The instant flow has exceeded the lower limit of the flow display range.	Ensure the flow is in the correct direction.
	LLL 200	The pressure has exceeded the lower limit of the pressure display range.	Increase the pressure to the display range.