

Valves

Solenoid Pilot Valves



01V

Pg. 14.4

Externally Piloted Solenoid Valves



01V - X1V

Pg. 14.10

Air Pilot Valves



01V

Pg. 14.24

Manual Valves



01V - X1V

Pg. 14.30


Mechanically Actuated Valves



01V

Pg. 14.40

Din Rail Mounted, Fixed Length and Modular Manifold Bases



01V

Pg. 14.43

Micro Valves



02V

Pg. 14.49

16 mm Valves



03V

Pg. 14.52

Micro Valves, Panel Mounted



04V

Pg. 14.56

Individual and Manifold Base Mounted Valves



05V

Pg. 14.59

Pedal Valves



06V

Pg. 14.67

Solenoid Valves



07V

Pg. 14.69

Miniature Solenoid Valves 10 mm



07V

Pg. 14.71

Miniature Solenoid Valves 15 mm



07V

Pg. 14.73

NAMUR Standard Valves



08V

Pg. 14.77

Valves ISO 5599 - Size 1



10V

Pg. 14.84

Valves ISO 5599 - Size 2



11V

Pg. 14.88


Solenoids and Connectors




Pg. 14.20 - Pg. 14.23

MANUAL, MECHANICAL, AIR PILOT AND SOLENOID PILOT VALVES

Valves





PANEL, PUSH BUTTON AND SELECTOR VALVES



MICRO VALVES

3/2



TAPPET - SPRING RETURN



Part No.	Function	Size	Pack.
02V G0 3 NC B5	3/2 NC	M5 (metric)	1
02V G0 3 NO B5	3/2 NO	M5 (metric)	1

3/2

PANEL MOUNTED ACTUATOR - SPRING RETURN



Part No.	Function	Size	Pack.
02V D0 3 NC B5	3/2 NC	M5 (metric)	1
02V D0 3 NO B5	3/2 NO	M5 (metric)	1

INTERFACE FOR CONNECTION BUTTON

Part No.	Pack.
04V 06 0 00 01	1
04V 06 0 00 02	1




04V 06 0 00 02

04V 06 0 00 01

PUSH BUTTON AND SELECTOR

PROTECTED PUSH BUTTON

Part No.	Standard Color	Pack.
04V 01 0 00 01	  	1



Part No.	Color	Pack.
04V 01 P 00 VE		1
04V 01 P 00 GI		1
04V 01 P 00 AZ		1



The following colors can be ordered separately.


AXIAL MONO-STABLE MUSHROOM

Part No.	Color	Pack.
04V 02 0 0N 01		1
04V 02 0 0R 01		1




TURN TO UNLOCK MUSHROOM

Part No.	Color	Pack.
04V 02 0 0R 02		1



KEY SELECTOR

Part No.	Color	Function	Position to pull the key out	Pack.
04V 03 0 00 01		0 - 1	Only in central position	1
04V 03 0 00 02		0 - 1	Both position	1
04V 03 0 00 03		2 - 0 - 1	Only in central position	1



SHORT LEVER SELECTOR

Part No.	Color	Function	Pack.
04V 04 0 0N 01		0 1	1
04V 04 0 0N 02		0 	1
04V 04 0 0N 03		2 0	1
04V 04 0 0N 04		2  0 	1



LONG LEVER SELECTOR

Part No.	Color	Function	Pack.
04V 05 0 0N 01		0 1	1
04V 05 0 0N 02		0 	1
04V 05 0 0N 03		2 0	1
04V 05 0 0N 04		2  0 	1

